


ROLLER CHAIN HOLDER

FOR #35 through #60 CHAINS

3/8" through 3/4" pitch



ACTUAL SIZE

A MUST WHERE ROLLER CHAIN IS USED

COMPACT - LIGHT - EASY TO USE

FOR A BROKEN CHAIN FIRST REMOVE BROKEN LINK PLATE WITH A ROLLER CHAIN BREAKER, HOLD THE CHAIN IN POSITION WITH CHAIN HOLDER, PRY OUT THE BROKEN LINK AND INSERT NEW MASTER OR REPLACEMENT LINK.

ALLOWS CHAIN TO BE PULLED, OR RELEASED WITHOUT DROPPING IN THE DIRT OR READJUSTING SPROCKETS WHEN REMOVING OR INSERTING MASTER LINK.

PKG. IN ZIP LOCK PLASTIC BAG.

PATENT NO. 3999738

MADE IN U.S.A.

GUARANTEED FOR 1 YEAR AFTER DATE OF PURCHASE AGAINST DEFECTIVE MATERIAL AND WORKMANSHIP

ESTABLISHED 1947

PATTON TOOL CO., INC. 67 Mainline Drive • Westfield, MA 01085

Tel (413) 564-5255 • Fax (413) 564-0018

Web Site: www.pattontool.com • E-mail: patton-tool@worldnet.att.net